TLP100IRB TLP100IRC
PROGRAMMING INSTRUCTIONS

NO WIRES CONNECTED

Picture: Upside down
Image: Reverse
Lines: No

BLUE, BLACK & WHITE CONNECTED

Picture: Right side up
Image: Reverse
Lines: Yes

BLUE & WHITE CONNECTED

Picture: Upside down
Image: Reverse
Lines: No

BLUE & BLACK CONNECTED

Picture: Upside down
Image: Reverse
Lines: Yes

WHITE & BLACK CONNECTED

Picture: Right side up
Image: Reverse
Lines: No

NOTE:
IF ANY CHANGES TO BE MAKE ON THE CAMERA. YOU MUST FIRST POWER DOWN THE CAMERA THAN MAKE YOU'RE CHANGES. AFTER YOU FINISHED YOU CHANGES POWER UP THE CAMERA AGAIN THE CAMERA WILL AUTOMATIC SAVE THE PROGRAMMING.