

INSTALLATION INSTRUCTIONS

PART# AE-6438

ALARM CIRCUIT:

Three-Wire N.O./N.C. Contacts for either closed or open circuit alarm systems. Simply connect the green (N.O.) and black (common) wires for closed circuit systems or the red (N.C.) and black wires for open circuit systems.

////ACCELE ELECTRONICS INC.

P.O. Box 92139 Long Beach, CA 90809 (800) 788 -1212 (310) 809-5090

INSTALLATION INSTRUCTIONS

PART# AE-6438

ALARM CIRCUIT:

Three-Wire N.O./N.C. Contacts for either closed or open circuit alarm systems. Simply connect the green (N.O.) and black (common) wires for closed circuit systems or the red (N.C.) and black wires for open circuit systems.

////ACCELE ELECTRONICS INC.

P.O. Box 92139 Long Beach, CA 90809 (800) 788 -1212 (310) 809-5090

INSTALLATION INSTRUCTIONS

PART# AE-6438

ALARM CIRCUIT:

Three-Wire N.O./N.C. Contacts for either closed or open circuit alarm systems. Simply connect the green (N.O.) and black (common) wires for closed circuit systems or the red (N.C.) and black wires for open circuit systems.

////ACCELE ELECTRONICS INC.

P.O. Box 92139 Long Beach, CA 90809 (800) 788 -1212 (310) 809-5090

INSTALLATION INSTRUCTIONS

PART# AE-6438

ALARM CIRCUIT:

Three-Wire N.O./N.C. Contacts for either closed or open circuit alarm systems. Simply connect the green (N.O.) and black (common) wires for closed circuit systems or the red (N.C.) and black wires for open circuit systems.

////ACCELE ELECTRONICS INC.

P.O. Box 92139 Long Beach, CA 90809 (800) 788 -1212 (310) 809-5090