


# ADJUSTABLE OUTPUT ADAPTOR




You may connect the ANI-35 either at the factory radio or at the rear speaker wires. You do not need to disconnect the speakers, the ANI-35 will work in conjunction with the speakers.

**NOTE:** In rare cases, if there is no sound coming from the aftermarket amplifier, connect both brown wires to the chassis of the radio.

\*Technical information and diagrams provided by Accele Electronics is "as is" information. User assumes entire risk and responsibility. Accele Electronics recommends verifying all wire colors and operation before installing product.

**//////ACCELE ELECTRONICS, INC.**

# ADJUSTABLE OUTPUT ADAPTOR



You may connect the ANI-35 either at the factory radio or at the rear speaker wires. You do not need to disconnect the speakers, the ANI-35 will work in conjunction with the speakers.

**NOTE:** In rare cases, if there is no sound coming from the aftermarket amplifier, connect both brown wires to the chassis of the radio.

\*Technical information and diagrams provided by Accele Electronics is "as is" information. User assumes entire risk and responsibility. Accele Electronics recommends verifying all wire colors and operation before installing product.

**//////ACCELE ELECTRONICS, INC.**